


14 LOW Power Head Spare Parts List



Part No	Description	Quantity
SP14LP00	SEAL KIT [3,5,6,7]	1
SP14LP01	BODY ASSEMBLY	1
SP14LP02	SCREW	1
SP14LP04	PISTON ROD ASSEMBLY	1
SP14LP08	END CAP	1
SP14LP09	SCREW	2
SP14LP10	SCREW	8
SP14LP11	ROD END	1
SP14LP12.2	FIXED UPPER PIN	1
SP14LP14	SECREW M6X12	2
SP14LP15	SCREW WITH SPRING	1


Part No	Description	Quantity
SP14LP16	SHORT LINK PIN	1
SP14LP17	RING	1
SP14LP18	SWIVEL ASSEMBLY 360°	1
SP14LP18a	SWIVEL ASSEMBLY 180°/360°	1
SP14LP19	1/4" NPT SCREW TYPE OUTER THREAD NIPPLE	1
SP14LP20	1/4" NPT SCREW TYPE OUTER THREAD BODY	1



14 LOW

Cassette Spare Parts List

TORC | TECH
Hydraulic Torque Wrenches



Part No	Description	Quantity
SP14LC01.1	RIGHT SIDE PLATE [85-90-95-100-105-110-115]	1
SP14LC02	BRASS BUSHING	2
SP14LC03	LEFT DRIVE PLATE [75-80-85-90-95-100]	1
SP14LC04	REACTION BLOCK EXTENSION	1
SP14LC05	HEX RATCHET [75-80-85-90-95-100]	1
SP14LC06	RIGHT DRIVE PLATE [75-80-85-90-95-100]	1
SP14LC07.1	LEFT SIDE PLATE [85-90-95-100-105-110-115]	1
SP14LC08	SCREW M16x40	4

Part No	Description	Quantity
SP14LC09	SCREW M8x20	2
SP14LC10.1	TOP SPACER	1
SP14LC11	ROLL PIN	1
SP14LC12	DRIVE PIN	1
SP14LC13	ROLL PIN	2
SP14LC14	DRIVE PIN SPRING	1
SP14LC15	SECONDARY DRIVE PAWL	1
SP14LC16	SPRING RING	1
SP14LC17	TENSION SPRING	1
SP14LC18	PRIMARY DRIVE PAWL	1
SP14LC19	SPRING SPACER	1
SP14LC20	TENSION SPRING	1

Part No	Description	Quantity
SP14LC21.1	ROLL PIN	1
SP14LC22	SPACER	2
SP14LC23.1	REACTION PAWL [85-90-95-100-105-110-115]	1
SP14LC24	SHROUD [85-90-95-100-105-110-115]	1
SP14LCERA	LONG REACTION ARM	1
SP14LCPAD	SHORT REACTION ARM	1